



You will need one of each of these guys in 1/8" balsa. Then get 1/16 balsa (you might need 2-3 square feet of this) and then 1/64" ply (same amount). Its always better to get more in case something goes wrong or you need to repair. Plot out at 32" by 18" and rubber cement to balsa grain running long ways. email if you have any other questions.