



TRANSOM DOUBLER
1/32" PLY 1 REQ'D

SPONSON DOUBLER
1/32" PLY
1 REQ'D

SET-SCREW BITES INTO DIMPLE IN 1/16 WIRE

GRIND THRU SS TUBE INTO 1/16 WIRE

1/16 PIANO WIRE

8 X SCALE

LOCK COLLAR, COUPLER OR PROPELLER DRIVE DOG

1/8 SS TUBE

5/32 OD BRASS TUBE

2.50 LONG STAINLESS TUBE

1/16 K&S PIANO WIRE

DRIVE DOG

LOCK COLLAR

1/8 OD X .028 wall X .5 LONG K&S STAINLESS STEEL TUBE

1

GLUE STANDOFFS TO TUNNEL STRIPS
GLUE SHAPED SUMP STRIP TO STANDOFFS
GLUE NOSE PIECES

2

SET TUNNEL & CONTROL PLATE ON BUILDING BOARD
ASSEMBLE STRINGERS, BULKHEAD-C AND TRANSOM
CHECK ALIGNMENT AND TACK GLUE

3

ADD ALL BULKHEADS
CHECK ALIGNMENT
FINAL GLUE ALL JOINTS

4

GLUE REAR NON-TRIP PANELS
GLUE DECK STRIPS TO TOP OF FRAMEWORK
GLUE SPONSON BOTTOMS THEN SIDES
GLUE SPONSON DOUBLER

5

CHECK DECK FIT, TRIM AS NEEDED
GLUE DECKING WITH CONTACT CEMENT
REMOVE CENTERS OF BULKHEADS B & C
GLUE FRONT & REAR DECK CENTERS
GLUE TRANSOM DOUBLER

Copyright 2006 Garry Finlay and Rum Runner Racing. All rights reserved, worldwide.

1/16th SCALE
1977 ATLAS VAN LINES
UNLIMITED HYDROPLANE for RumRunnerRacing
01/13/06 by: G.Finlay SHEET 2 of 2